


## SAILOR 6090 Power Converter

Installation guide



## **Dimensions** 33mm 0 85mm 0 190mm Drilling plan 4 x M4 or hole for self-tapping ø3.9 60mm $8\,\text{mm}$ 174 mm

## **Technical specifications**


 Efficiency (typical):
 >94%

 Fuse type:
 10A ATO mini

 Current limit:
 8A@12.5V

 Current limit:
 7A@15V

Note: The Power Converter is short-circuit protected at the output, it means that a short circuit will not cause the fuse to burn.



Manufacturer: Thrane & Thrane A/S, Lundtoftegårdsvej 93D, DK-2800 Kgs. Lyngby, Denmark Industrivej 30, DK-9490 Pandrup, Denmark

**EU Declaration of Conformity:** Thrane & Thrane A/S declares that the equipment complies with the specifications of the Electromagnetic Compatibility Directive (EMC) 2014/30/EU and the Low Voltage Directive (LVD) 2014/35/EU. The full text of the EU Declaration of Conformity is available at the internet address: https://sync.cobham.com/satcom/products/maritime/power-supply.

**Disclaimer:** Any responsibility or liability for loss or damage in connection with the use of this product and the accompanying documentation is disclaimed by Thrane & Thrane & Thrane A/S. The information in this manual is provided for information purposes only, is subject to change without notice and may contain errors or inaccuracies. The manuals are periodically revised and updated. Anyone relying on this information should acquire the most current version e.g. from cobham.com/satcom or from the distributor. Thrane & Thrane A/S is not responsible for the content or accuracy of any translations or reproductions, in whole or in part, of this manual from any other source. Thrane & Thrane A/S trading as Cobham SATCOM. Copyright © 2017 Thrane & Thrane A/S. All rights reserved.